Soot load vs DP characteristic measurement on the DPG

Introduction

Measurement of backpressure as a function of soot load is an important application for the DPG, both in development and production QA applications.

The DPG allows the measurement of such characteristics with good reproducibility, with several advantages over engine testing and other rigs:

- Soot output rate is constant without any effect from the variable backpressure of the DPF.
- Low levels of NO₂ avoid any uncertainty in the soot level due to passive regeneration effects.
- The system can be operated with the burner on but with no soot generation, to distinguish the effect on the backpressure of warming up and pore filling.
- Uncanned filters can be tested easily in the Filter Test Housing.
- The multi-stage test required can run automatically, with manual intervention only required for weighing the filter.
- The flow rate and temperature are independently controlled, and the system automatically corrects for variations in atmospheric pressure.

In the standard loading test, the filter is loaded to a little higher than the soot load of interest, and is weighed at the start and end of loading to determine the actual soot load: therefore any day to day variability in the soot load rate does not affect the data. The backpressure is logged continuously, and the backpressure at the load of interest is read from the logged data. These calculations, and the checking against part-type specific limits, is automated by the DPG software.

Summary/ typical data

The following conditions are recommended for backpressure testing:

	DPF volume	DPF flow	DPF temperature
Light duty systems	up to ~ 51	250 kg/h	240°C
Medium duty systems	above ~51	400 kg/h	240°C

The procedure (described in detail below) can be summarised as:

- 1. Stabilise airflows/ warmup fuel nozzle
- 2. Light burner and warm DPF under test without soot
- 3. Hold DPF at temperature until operator is ready for zero weight
- 4. Weigh DPF
- 5. Relight burner and warm DPF back up
- 6. Switch to soot loading condition and load for prescribed period
- 7. Switch to no soot condition and hold DPF at temperature for weighing
- 8. Weigh DPF

The diagram below shows a typical characteristic for the DPF pressure drop plotted vs time.



The backpressure is normally evaluated against the soot load determined from the empty and loaded weighings: this is shown below.

The diagrams indicate the 'pore filling' and 'cake formation' phases which are typical of loading of clean DPF parts. The data corresponds to 4 tests on the same part, tested twice on 2 different DPG systems.



Automatic Test report

The DPG system generates a summary report of data from a loading test (among other standard tests). The report is a .pdf file and an example is shown below.



Operating Procedure

Fresh parts should be conditioned in the oven at 650°C for one hour before testing, or put through a DPG regeneration cycle; this is to stabilise the part weight and avoid errors in the soot mass measurement.

Ensure part orientation is correct in the Filter Test Housing.

For measurements at a given desired load, the DPG should be configured to load to a mass 10% higher to ensure there is enough mass on the part given variability in the loading rate.

The test Filter can should have an inlet face thermocouple fitted which should be connected to DPF 1 input.

If required, empty backpressure should be assessed from cold flow conditions before the burner is lit. Note that measurements during warm up are not reliable due to the extremely rapid variation of backpressure with tiny quantities of soot during the pore filling phase.

DPG Schedule Setup

Selleadle ealtor	1			-									
Ablaufprogramm	Modus		Dauer	DPF s	strom	DPFT	em	Abschlus	s dialo	3		15.7	
)g soot load	Stabilise	and the second	00:20:00	250	and the second	50		and the second second	State and	1000	Class Children		
g AVL Check	Warmup cold start		00:20:00	250		240							
al 2ry & 3ry	🔀 warmup base fuel		00:05:00	250 240				Ready for Clean Weight					
o characteristic load 15g	🛛 🔀 Weigh		00:00:00	0		0 Start Weight							
PFeffVW	🔀 LeakCheck		00:00:00	60		0		Pause to	cure DI	vIC leak	< - Continue	e wh	
egen	warmup base fuel		00:05:00	250		240							
egen cool down	10g per hour load		01:40:00	250		240		Loaded v	/eight				
nort efficiency	🔀 warmup base fuel		00:00:01	250		240		waiting fo	r loade	d weigh	ighing		
stflow	🔀 Weigh	00:00:00	0		0		Loaded V	Veight					
ariable soot load	Standby		00:00:00	0		0							
arm up													
eighed Efficiency													
	Bent medicalm												
	Troport specific data T	Default VW race track		Subsection.	in the second			(1997) 					
	Gewicht	UP correction			Mass (g	Enable	DpMir	DpMax	Enable	EffMin	EffMax		
	and the second se	✓ To reference pressure (mbar)	1013,25		2		(Null)	(Null)		(Null)	(Null)		
	Loaded Weight				12	Г	(Null)	(Null)		(Null)	(Null)		
		Reference to DPF: . In .	Out	*									
	J¢ minus		Contractor										
	Start Weight	To reference temperature (*C) 240										
		Contraction of the second	and the second second										
	Content	T/C DPF1T	emperatur 💌										
	VPr Druckabtall	To reference flow (kg/hr)	250										
	- DPF												
	Filterwirkungsgrad												
	E Flow sweep												
	1 Trow sweep		645,6466,670										
				Ge	samtd	auer	02:3	101	OK	1	Abbruch	X	
			Zi	el Rußbe	eladun	a (a)	13,2			1000		•	

DPF temperature control should be from a DPF inlet face thermocouple. Dp correction should be set up for

- to reference pressure of 1013.25 referenced to DPF In
- no correction for flow or temperature (these are controlled)
- The Schedule should be configured with the flow and temperature recommended previously.

Configure reporting points at the soot loads required for various parts. Typically, soot loads corresponding to 0.5 g/l for an 'end of pore filling' condition, and 4.4 g/l for a loaded condition are recommended.

The report specification should be set up for (Loaded weight – start weight), and including the DPF backpressure graph.

Phases to include:

1. Stabilise mode for 20 minutes or until fuel nozzle temperature reaches 50°C.

Vame	Wert Einhe	n Modus abschluss trigger. Dieses hebt die voreingestellte Dauer auf.	Uberwachungssystem
?rimärer Luftstrom jekundärer Luftstrom jemperatur des primären Luftstroms	18,940 kg/h 155,040 kg/h 75,0 C	✓ Einschalten Trigger-Niveau Verführtes Triggereimale.	Einschaken Probenahmezeit Anfängliche
emperatur sekundärer Luftstrom raftstoffstrom /entil für Tertifärstrom einschalten bigasentnahmeventil öffnen inwartete Rußerzeugungsrate	50,0 C 0,000 kg/h True False 0 g/hr	Sol test test Set at test	vor Filter (s) Probenahmezet nach Filter. 20000 200 200 200 200 200 200 200 200 2
nginterval 1	184 - 624	Trigger-Richtung ↔ Analoge Ausgänge C Fallend ↔ Digitale Ausgänge ⊕ Digitale Ausgänge ⊕ Regler	
PF Temperatur 50	35 - 96	Triggersignal I Ditemperatur der Düse (C)	
oreingestellte auer (hhr.mm.ss)	•	Abschluss dalog für modus	Total monitoring duration 0 (00.00:00)

2. Warm up 20 minutes or until burner body achieves 45°C. Upstream AVL measurements may be performed in this phase to confirm no significant generation of particulate in the clean mode.

Ausgewählter nanueller Modus	Warmup cold sta	t	•				
Name	Contractory of the state	Wert	Einheiten	Modus abschluss (rigge	r. Dieses nebt die voreingestellte Dauer aut.	Uberwachungssystem	
Primärer Luftstrom Sekundärer Luftstri Temperatur des pri	om mären Luftstroms	18,940 155,040 75,0	kg/hr kg/hr C	Einschalten	Maria and Andrews	Finschalten Probenahmezeit	Anfängliche
Temperatur sekund	lärer Luftstrom	50,0	C	45	Developate Higgersignale	vor Filter (s)	Probenahmezeit nach Filter
Ventil für Tertiärstro Abgasentnahmeve	m einschalten ntil öffnen	T,300 True False	kg/hr	Set at test	Detechnungen Analoge Eingänge Eingänge	20000	200 ÷
Erwartete Rußerze	ugungsrate	0	g/hr		Temperatur	Dates Auf #	Unten #P. Wiede
_og-Interval	10 🚊	185-625		Trigger-Richtung C Fallend C Steigend	 Analoge Ausgänge Digitale Ausgänge Regler 		
	<u>j250</u>	100 020		Timeral	- I - I - I - I - I - I - I - I - I - I		
DPF Temperatur	240	242 - 301		Burner body tem	perature (C)		
Voreingestellte Dauer (hh:mm:ss)	00:20:00			Abschluss dialog für mod	lus	Total monitoring duration	0 (00:00:00)
				Dialog-Typ	·		
DK A		۵	bhuch V	Beschreihung	the second s		

3. Warm up 5 minutes at the standard flow conditions, continued until operator is ready to weigh part

		uluuu					
C ⁷ Automatische	Moduseingabe						اللا (ب
Ausgewählter manueller Modus	warmup base fuel	-	•				
Name	No. of the second second	Wert	Einheiten	Modus abschluss trigger	. Dieses hebt die voreingestellte Dauer auf.	Uberwachungssystem	
Primärer Luftstrom Sekundärer Luftstr Temperatur des pri Temperatur sekun	om mären Luftstroms Härer Luftstrom	18,940 155,040 50,0 50,0	kg/hr kg/hr C	Einschalten Trigger-Niveau	Verfügbare Triggersignale	Finschalten Probenahmezeit vor Filter (s)	Anfängliche Probenahmezeit
Kraftstoffstrom Ventil für Tertiärstro Abgasentnahmeve	m einschalten ntil öffnen	1,100 True False	kg/hr	0 Fill Set at test	 Berechnungen Analoge Eingänge Digitale Eingänge 	20000	nach Filter.
Log-Interval	10	U	g/nr	Trigger-Richtung	Temperatur Analoge Ausgänge Digitale Ausgänge Bi Digitale Ausgänge Bi Regler	Date: Auf #f	Unten #P_ Wedeh_
DPF strom	250	185 - 625		 Steigend Triggersignal 	•		
DPF Temperatur	240	208 • 268		Nichts			
Voreingestellte Dauer (hh:mm:ss)	00:05:00			Abschluss dialog für mod	us /arten	Total monitoring duration	200 (00:03:20)
ок 🖌		A	bbruch 🗙	Beschreibung R	eady for Clean Weight		

4. Weigh and measure temperature of part.

> Automatische Moduseingabe						
usgewählter Weigh		•				
Name	Wert	Einheiten	Modus abschluss trigge	r. Dieses hebt die voreingestellte Dauer auf.	Uberwachungssystem	
nemen Unterom Trenperiou Jahrom Trenperiou Jahrom Trenperiou Jahrom Kraftstöftsom Ventil für Terlisättom enschaften Abgesenhahmeventil öffnen Erwartete Rußerzeugungsrate ogrinterval	0,000 0,000 0,0 0,0 0,000 False False 0	kg/hr kg/hr C C C kg/hr	Einschalten Trigger-Niveau	Verfügbare Triggersignale Berechnungen Analoge Engänge Digitale Eingänge Temperatur Analoge Ausgänge Digitale Ausgänge Regier	Einschalten Probenahmezeit vor Filter (s) 20000	Anlängliche Probensimezeit noch Filter. 200 + * 2 Octen: BP: Winder
Pr stion	0.0		Trianguitard			
PF Temperatur	0.0		Nichts			
foreingestellte Jauer (hhr.mm:ss)	8		Abschluss dialog für mor Einschalten Dialog-Typ	tus viege DPF	Total monitoring duration	0 (00:00:00)
ок 🖌		Abbruch 🗙	Beschreibung S	tart Weight		

5. Warm up 5 minutes

anueller Modus			Modus abschluss trigge	r. Dieses hebt die voreingestellte Dauer auf.	- Oberwad	hunassvi	stem			
lame	Wert	Einheiten								
rimärer Luftstrom	18,940	kg/hr	Einschalten		🔽 Ein:	schalten				
ekundärer Luftstrom	155,040	kg/hr								
emperatur des primären Luftstroms	50,0	C	Trigger-Niveau	Markinkana Trimenianala	Prober	ahmezeit		Anfang	liche	
emperatur sekundärer Luftstrom	50,0	C		verrugbale miggelsignale	vor Filb	er (s)		Proben	ahme:	zeit
raftstoffstrom	1,100	kg/hr	0	E Berechnungen				nach F	itter.	
entil für Tertiärstrom einschalten	True		- and the second	🗄 Analoge Eingänge	20000			200		+
bgasentnahmeventil öffnen	False		l bet at test	💮 표 Digitale Eingänge 👘	a secondario	1000	1000	Section 1	126-12	Carrier Contra
rwartete Rußerzeugungsrate	0	g/hr		🗄 🕀 Temperatur	Dauer	Auf	#P_	Unten	#P	Wiederh
			Tripper-Bichtung	🔍 🕀 Analoge Ausgänge	150	Г	0	Г	0	0
g-Interval 10			ringgor i horkang	E Digitale Ausgänge	150	R	1	Ē	0	9999
and the second se			C Fallend	Benler	1.00					0000
States and states and a supervised states of the	and the second		C Durant	E ridgior						
7 strom 250	185 - 625		** preigent							
			Triggersignal	•						
PF Temperatur 240	208 - 268		Nichts							
Le lo			principal							
reingestellte 00:05:00			Abschluss dialog für mod	lus	Total moni	toring due	ation	300.0	00.05	001
auer (hhrmm:ss)					rotarmora	coming com	GUIDET			00)
			Einschalten							
			Distantin							
the second se			Dialog-ryp	and the second						

6. Load at 10 g/hr.



- 7. Warm up until operator is ready to weigh part
- 8. Weigh and measure temperature of part.

Other Operating Procedures.

In order to achieve repeatable and reproducible results, we recommend several other operating procedures:

- 1. Follow the guidelines for FTH part fitting and FTA seal life in the FTH manual. In particular, the seals are validated for a life of 5 tests, but should not be exposed to a regeneration in this life.
- 2. Reference filters should be tested regularly, to confirm the stability of the DPG.
- 3. Follow the procedures in Cambustion process DPG016 to confirm the stable operation of the unit.

Refer to Cambustion Application note DPG007 for typical repeatability results from this testing.

Cambustion DPG001v02

Criteria for Valid Test

Weighed (corrected) mass achieved should be at least 95% of desired soot mass.

DPF temperature at weighing should be at least 200°C

Soot concentration in the first warm up phase measurement should not exceed $2mg/m^3$ – this corresponds to less than 0.01g deposited soot.

Flow rate during the test should not fall below 95% of the desired flow.

No hardware failures should occur during the test.